

Weatherproof telephone

INDUTEL IP



Operating manual



Note

Before installing the equipment, these operating instructions are to be read carefully. It is to be checked that the contents of the packaging are complete.

Contents

General notes on operation	3
At the time of delivery	4
Contents of the packaging.....	4
Default settings of the telephone	4
Assembly and installation	5
Wall assembly	5
Connection of a separate DC voltage supply	5
Connection of the internal relay contact	5
Terminal configuration	5
Assembly of RJ45 connector.....	6
Operating elements	6
Execution with keypad	6
Dimensions	7
Operation	8
Calling / taking call	8
Dialing	8
Speed dialing	8
Re-dialing	8
Disconnecting.....	8
Web server	9
Authentication	9
Menus	10
Info	10
Info	10
About.....	10
System Details	10
Configuration.....	11
Network Settings	11
Phone Settings.....	12
Audio Settings.....	13
Speed Dial.....	14
System Administration.....	16
Change Password	16
Manual Upgrade	16
General notes	17
Service	17
Servicing and maintenance	17
Warning and safety instructions	17
Technical data	18
Declaration of conformity	19
Directives	19
Disposal	19

General notes on operation

1. The InduTel IP is the VoIP (Voice over Internet Protocol) version of the telephone InduTel and is operated on a 10/100 BaseT Ethernet network. The connections are established with the Session Initiation Protocol (SIP). The operation corresponds to that of an analogue telephone.
2. The power supply takes place via Power over Ethernet (PoE) from the network or via a separate direct current voltage source.
3. The programming and parameter setting are carried out solely via the web server of the telephone. The web server can be reached via the standard web browser of a PC. In order to access the web server, entering the username and the password is necessary. The factory settings for the username and password are:

Username: admin

Password: fhf

The preset IP address is 192.168.0.77

4. The telephone has a handset rest with a magnetic contact as a hook switch. In order to terminate an existing connection, the handset must be hung up. To interrupt an existing connection, it is sufficient to press the cut-off key on the keypad.
5. The internal relay contacts only allow tensions of 30 VAC or 60 VDC to be switched. The maximum permissible current depends on the mode of operation (see chapter Technical Data)
6. The network connection (LAN) is established via a housing connector.
7. The handset of the telephone is fitted with a stray field coil for connection to hearing aids. Those who wear a hearing aid with an inductive receiver can receive the signal of the earphone capsule directly over the hearing aid.

At the time of delivery

Contents of the packaging

- Telephone InduTel IP
- These operating instructions
- LAN device connector plug

Default settings of the telephone

IP address	192.168.0.77
Netmask	255.255.255.0
Announcement of the current	Dial *558800
Master Reset to Factory	Dial ** 314159265359
Username	admin
Password	fhf
Number redial memory	Empty
Speed dial memory	Empty
Relay function	Switched off
Tone call melody	2
Tone call volume	3
Handset volume	5
Microphone sensitivity	6

Assembly and installation

Since all telephones have the same preset IP address, the network settings should be made on the web server of the telephone before the telephone is assembled. The username and password at the time of delivery should be changed for security reasons. The assembly of the telephone should only be carried out by qualified specialist personnel.

Wall assembly

Assembly is carried out on a firm and even surface.

Fasten the telephone to the wall with four screws (of a size of up to Ø 8 mm).

Attach the LAN device connector plug provided to the LAN cable available onsite and connect the device connector plug with the telephone.

Connection of a separate DC voltage supply

If a PoE supply is not available, the telephone can also be operated with a DC voltage of 24 V to 48 V.

Take off the handset. Unscrew the keypad plate. Guide the supply line through the screwed cable gland and put the two connecting leads onto the terminals 3 and 4 (any polarity). Fix the supply line with the cable gland. Make sure that the cable connection to the keypad is plugged in. Then place the keypad plate back onto the telephone and fasten it with four screws. Then put the handset back.


Connection of the internal relay contact

Take off the handset. Unscrew the keypad plate. Guide the connection line through the screwed cable gland and put the two connecting leads onto the terminals 1 and 2. Fix the connection line with the screwed cable gland. Make sure that the cable connection to the keypad is plugged in. Then place the keypad plate back onto the telephone and fasten it with four screws. Then put the handset back.


Only use lines with a sheathing diameter of 5 mm to 9 mm, since the degree of protection IP 66 is not ensured otherwise. If you wish to use a separate DC voltage supply and the relay contact at the same time, you must use a four-core cable.

If a separate DC voltage supply and connection of the internal relay contact are not required, it is to be ensured that the sealing element is in the screwed cable gland.

Terminal configuration



Assembly of LAN-Connector RJ45




PIN assignment depends on the condition of installation on site



recommended tool:
LogiLink Crimpzange Universal
WZ0003


Operating elements

Execution with keypad



Dimensions

* Drilling dimensions



Operation

Calling / taking call


If you take off the handset, you can take a call or dial the number of the person you wish to speak to.

Dialing

You can enter the desired telephone number using the number keys. Once a connection has been established, you can transmit tone dialing signals with the number keys and the star and hash key.

Numbers are dialed in so-called block dialing. This means that the numbers must be entered quickly one after the other. After a pause of a certain length, the numbers entered so far are then dialed.

Speed dialing

With the key  and then a number key you can dial telephone numbers you saved previously using the web server of the InduTel IP.

Re-dialing

After taking off the handset and pressing the redial key, the telephone number last entered will be automatically dialed as long as the InduTel IP has not been restarted.

Disconnecting

If you want to end a conversation and start a new one straight away, you do not need to hang up the handset but merely press the cut-off key. The old conversation will be terminated through the connection being cut and after a short time you will hear the dial tone. You can now enter the telephone number for the new conversation.

Announcement of the current IP address

The InduTel IP is able to announce the current IP address. For this purpose, the following “telephone number” must be dialed:

IP announcement = *558800

The address will be announced on the telephone earpiece.

Web server

This section describes the administration/configuration of the telephone InduTel IP. All functions and properties of the telephone can be set via the web server.

IMPORTANT / GENERAL NOTE:
BEFORE PARAMETERS CAN BECOME EFFECTIVE THEY HAVE TO BE SAVED
WITH “APPLY CHANGES”.

In the case of certain parameters, the InduTel IP must be restarted in order for them to become effective.

Authentication


The web server is accessed via a web browser. You should use an up-to-date version of a commonly used web browser.

The preset static IP address of the telephone is:

IP-Address: 192.168.0.77
Mask: 255.255.255.0

You will be requested to enter a username and a password.
The factory settings for the username and password are:

Username: admin
Password: fhf



Authentication Required

A username and password are being requested by http://192.168.0.77. The site says: "FHF IP3"

User Name:

Password:

Menus

The web server is the central control unit and is divided into various main menus and submenus, which are arranged on the left-hand side.

Info

Info

If you have successfully authenticated, you will be taken to the main menu “Info” and the submenu of the same name.

This browser page is divided into four sections:

Device Info: Device and network parameters are displayed here

SIP Configuration: SIP account settings are displayed here

Status: This part indicates which state the telephone is in (unregistered, ready, dialing, startcall, talking, busy, incoming, callended, fault) and what the registration status of the PBX is (auth., request, registered, failed, -)

Version: The current hardware and software version are shown here.



The screenshot displays the web interface of FHF Funke + Huster Fernsig GmbH. The header features the company name and the tagline 'Signalling Devices and Communication Equipment' over a background image of circuit boards. On the left, a navigation menu lists 'Info', 'Configuration', and 'System Administration'. The 'Info' section is active, showing four sub-sections: 'Device Info', 'SIP Configuration', 'Status', and 'Version'. Each section contains specific technical data for the device.

Device Info	
IP-Address	192.168.0.77
Netmask	255.255.255.0
Gateway	192.168.0.1
DHCP-client	off
MAC-Address	00:50:C2:6A:55:47

SIP Configuration	
Codec	G.711
SIP User Name	
SIP Display Name	
SIP ID	** <>
SIP PBX1	0.0.0.0
SIP PBX2	0.0.0.0

Status	
Telefon State	ready
PBX1 Registration State	Sent
PBX2 Registration State	-

Version	
HW Version	InduTel_IP 1.0
SW Version	1.0 r795

At the bottom of the 'Info' section, there is a button labeled 'Reboot Phone'.

About

The GNU license terms are given in the submenu “**About**”.

System Details

In the submenu “System Details” there is additional information for the administrator. Moreover, the functions “**PING**” and “**TRACE ROUTE**” are available with which another IP address can be pinged or traced from the telephone.

NOTE: The “**TRACE**” command in particular can take up a great amount of time. Even if the web server indicates a “**Timeout / Refresh Error**” of the page, the “**TRACE ROUTE**” or “**PING**” command is still active in the background and the result can be shown later on by means of “**Show Last Ping**” or “**Show Last Trace**” – as long as no reboot or the like interrupts the execution of the command. It is therefore recommended to limit the number of pings or hops and start with a small number (one or two) and to increase these step by step if necessary.



FHF Funke + Huster Fernsig GmbH
Signalling Devices and
Communication Equipment

Info
Info
About
System Details

Configuration
System Administration

System Tests

IP to ping:

Number of pings:

IP to trace:

max. hops:

System Data

fhf IP3

Revision-Number: r795

Stored Static IP: *192.168.0.77*
Current IP: *192.168.0.77*

Stored Netmask: *255.255.255.0*
Current Netmask: *255.255.255.0*

Configuration

In order to save the entered data on the following menus, the **“Apply Changes”** button must be clicked on.

So that the changes become effective, the telephone must be restarted (“reboot”).

Network Settings

In this submenu you can choose whether the IP address is to be assigned dynamically via the network (DHCP) or manually. In the case of manual assignment, the fields **“Subnet Mask”** and **“Gateway Address”** must additionally be entered in keeping with the network parameters. You can also configure the IP address of an NTP server so that the date and time in the bottom left-hand corner of the web server are shown correctly. Inserting the NTP address via DHCP is not possible.



The screenshot displays the web interface for FHF Funke + Huster Fernsig GmbH, specifically the 'Network Settings' page. The header features the company logo and name, along with the tagline 'Signalling Devices and Communication Equipment'. A left-hand navigation menu includes 'Info', 'Configuration' (with sub-items: Network Settings, SIP Settings, Phone Settings, Audio Settings, Speed Dial), and 'System Administration'. The main content area is titled 'Network Settings' and contains sections for 'Dynamic IP Settings' (with radio buttons for DHCP and static IP), 'Static IP Settings' (with a note 'Only active if DHCP = off' and input fields for IP Address, Subnet Mask, and Gateway Address), and 'Additional Settings' (with an input field for NTP Server). At the bottom, there are buttons for 'Apply Changes' and 'Reboot Phone'.

Network Settings	
Dynamic IP Settings	
IP Mode	<input type="radio"/> DHCP <input checked="" type="radio"/> static IP
Static IP Settings	
Only active if DHCP = off	
IP Address	<input type="text" value="192.168.0.77"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>
Gateway Address	<input type="text" value="192.168.0.1"/>
Additional Settings	
NTP Server	<input type="text" value="0.0.0.0"/>
<input type="button" value="Apply Changes"/>	
<input type="button" value="Reboot Phone"/>	

You will find all settings relating to SIP here. There are 4 sections altogether.

In this section “**User ID**”, “**Displayname**”, “**Phone Number**” and “**Domain**” can be set. If “**Displayname**” as well as “**Phone Number**” are set, the “**Displayname**” will be used for registration on the PBX.

There are two parameters for setting the PBX IP. This is the IP address which the telephone registers at. The parameter **“Backup PBX”** is only used however if **“PBX Alternation enabled”** is selected further down on the webpage. With **“SIP Port”** a port can be set between 5.000 and 31.000 for the SIP connection.

“Register Attempts” specifies the number of registration attempts before the telephone gives up trying to register. A value of zero corresponds to an infinite number of attempts. **“Register Timeout”** indicates the time in seconds that passes after each failed attempt before the telephone makes another attempt. With **“Qualify Connection”** is used to define a certain time span until the InduTel IP monitors if a previously established PBX connection still existed.

“Speed Dial” activates the feature of the same name (see Operation) and can be combined with **“Call Transfer”**. **“PBX Alternation”** activates permanent switching between the two given PBX IP addresses after a certain number of failed registration attempts (see **“Register Attempts”**).

If registration at one of the two PBX IP addresses was successful, the InduTel IP will monitor this connection. If the connection breaks down, the procedure of permanent alternation will restart until one of the two PBXs can be reached again.

www.malux.se

Phone Settings

You can configure the “hardware behavior” of the InduTel IP here.

Relay Activation:

There are five options available. “on/off” generally switches the relay on or off. If “incoming call” is selected, the relay switches to “on” for as long as there is an incoming call. Selecting “active call” on the other hand ensures that the relay is on “on” for as long as an existing connection is active. The “switch” function makes it possible for the relay to be controlled locally from the InduTel IP.

Switch Function:

The code is entered here which must be entered via the keypad (an “internal call” is involved) when the handset is off its hook in order for the relay to jump to “on” for a certain period of time (**time parameter**) before falling back into the “off” status again. The dialed code is no longer available as a telephone number.

Handset Rest Lights:

With this parameter, the handset rest lighting can either be turned on or off or be configured as an additional optical signal. If the point “incoming call” is selected, the LEDs start flashing while the InduTel IP rings.

Keypad Backlights:

The keypad backlights can be turned on or off. In addition, it is possible to set them to only going on when the handset is off its hook by selecting “off hook”.



The screenshot shows the web interface of FHF Funke + Huster Fernsig GmbH. The header features the company name and logo, with the tagline "Signalling Devices and Communication Equipment". The interface is divided into a left sidebar and a main content area. The sidebar has two sections: "Info" and "Configuration". The "Configuration" section is expanded, showing a list of settings: Network Settings, SIP Settings, Phone Settings (which is selected), Audio Settings, and Speed Dial. Below this is a "System Administration" section. The main content area is titled "Phone Settings" and contains several configuration options: "Handset Rest Lights" set to "incoming call", "Keypad Backlights" set to "off hook", and "Relay Activation" set to "off". Below these is a "Switch Function" section with a note: "Only active if 'switch' is selected in the 'Relay Activation' settings." This section includes a "code" field with the value "1234" and a "time (sec.)" field with the value "10". At the bottom of the main content area are two buttons: "Apply Changes" and "Reboot Phone".

FHF Funke + Huster Fernsig GmbH

Signalling Devices and Communication Equipment

Info

Configuration

- Network Settings
- SIP Settings
- Phone Settings
- Audio Settings
- Speed Dial

System Administration

Phone Settings

Handset Rest Lights: incoming call

Keypad Backlights: off hook

Relay Activation: off

Switch Function

Only active if "switch" is selected in the "Relay Activation" settings.

code: 1234 time (sec.): 10

Apply Changes

Reboot Phone

Audio Settings

The settings for the handset, the ring tone and the country-specific signaling tones are made in this menu.

Ringer Settings:

“**Ringling Time**” indicates how long the InduTel IP is to ring for before an incoming call is refused. The volume can be changed using the “**Volume**” control. The ring tone is selected via the “**Melody**” control.

Handset Settings:

The receiver volume and microphone sensitivity are set for the handset here.

Indication Settings:


The signaling tones can be localized under this subitem. If “**Custom**” is selected, the InduTel IP plays the tones previously installed by the user (cp. Section “Manual Upgrade”).



The screenshot displays the web interface of FHF Funke + Huster Fernsig GmbH. The header features the company name and the text "Signalling Devices and Communication Equipment" over a background image of circuit boards. A left sidebar contains a navigation menu with categories: "Info", "Configuration" (sub-items: Network Settings, SIP Settings, Phone Settings, Audio Settings, Speed Dial), and "System Administration". The main content area is titled "Audio Settings" and includes three sections: "Ringer Settings" with fields for "Ringing Time" (150 seconds), "Volume" (3), and "Melody" (2); "Handset Settings" with "Speaker Volume" (5) and "Microphone Sensitivity" (6); and "Indication Settings" with a "Select Country" dropdown set to "Europe PBX". At the bottom are "Apply Changes" and "Reboot Phone" buttons.

Audio Settings	
Ringer Settings	
Ringing Time:	<input type="text" value="150"/> seconds
Volume	<input type="text" value="3"/>
Melody	<input type="text" value="2"/>
Handset Settings	
Speaker Volume	<input type="text" value="5"/>
Microphone Sensitivity	<input type="text" value="6"/>
Indication Settings	
Select Country	<input type="text" value="Europe PBX"/>
<input type="button" value="Apply Changes"/>	
<input type="button" value="Reboot Phone"/>	

Speed Dial:

In the submenu “**Speed Dial**” you can assign a telephone number to each number key. When speed dialing with the key sequence “”, number key”, the telephone number assigned to the number key will then be dialed if activation has been carried out under “**SIP Settings Speed Dial**”.



The screenshot displays the web interface of FHF Funke + Huster Fernsig GmbH. The header features the company name and logo, along with the text "Signalling Devices and Communication Equipment". The main content area is titled "Speed Dial Settings". On the left, there is a sidebar menu with "Info" and "Configuration" sections. The "Configuration" section includes "Network Settings", "SIP Settings", "Phone Settings", "Audio Settings", and "Speed Dial". The "Speed Dial" option is selected. The main area shows a list of keys (Key 0 to Key 9) with corresponding input fields for assigning telephone numbers. At the bottom, there are buttons for "Apply Changes" and "Reboot Phone".

Key	Number
Key 0	<input type="text"/>
Key 1	<input type="text"/>
Key 2	<input type="text"/>
Key 3	<input type="text"/>
Key 4	<input type="text"/>
Key 5	<input type="text"/>
Key 6	<input type="text"/>
Key 7	<input type="text"/>
Key 8	<input type="text"/>
Key 9	<input type="text"/>

System Administration

Username & Password

In this submenu you can change the username and the password.



The screenshot shows a web interface for FHF Funke + Huster Fernsig GmbH. The header features the company name and logo, along with the text "Signalling Devices and Communication Equipment". The main content area is divided into a left sidebar and a right main panel. The sidebar contains a menu with "Info", "Configuration", and "System Administration". Under "System Administration", there are links for "Username & Password", "Manual Upgrade", and "Reset Settings". The main panel displays the "Username & Password" settings. It includes a "Current Settings" section showing the current username as "admin" and the current password as "*****". Below this is a "New Settings" section with three input fields: "Current Password", "New Username", and "New Password". A "Verify Password" field is also present. At the bottom of the main panel, there are two buttons: "Apply Changes" and "Reboot Phone".

FHF Funke + Huster Fernsig GmbH
Signalling Devices and Communication Equipment

Info
Configuration
System Administration
Username & Password
Manual Upgrade
Reset Settings

Current Settings
Current Username admin
Current Password *****

New Settings
Current Password
New Username
New Password
Verify Password

Manual Upgrade

In this submenu you can perform a telephone software upgrade. The greatest care is to be taken in doing so. It is to be ensured that only one InduTel IP ever accesses the TFTP server at the same time, since a corruption of the transferred data will be caused otherwise and ultimately a failed upgrade process.

NEVER USE THE UPDATE FUNCTION IF STEP 2 WAS NOT SUCCESSFUL!

The parameter "Automatic Reset to Default Settings" defines if your current user settings will be kept or deleted when executing step 3a.

Step 1: Press the **"Save Settings"** button and check carefully whether the shown settings are correct.

Step 2: Check whether there is a connection to the tftp server by means of **"Probe Connection"**. For this purpose, the file designated in **"Enter Testfile Name"** is downloaded** from the given server by means of tftp and, if successful, the content is shown on the webpage. If this is not successful, an error message appears.

In order to avoid complications please use as small a file.txt as possible with as about as little content as **"Download Successful".

Step 3a: Start the update by means of **"Update Now"**

or

Step 3b: Install a new set of tones by means of **"Install Sounds"**

Info Configuration System Administration Username & Password Manual Upgrade Reset Settings	Update Server Settings	
	Enter Update-Server IP	<input type="text" value="0.0.0.0"/>
	Enter Testfile Name	<input type="text" value="alive.txt"/>
	Enter Image Name	<input type="text" value="ulimage.ext2"/>
	Enter Busytone File-Name	<input type="text" value="busytone.wav"/>
	Enter Dialtone File-Name	<input type="text" value="dialtone.wav"/>
	Enter Ringtone File-Name	<input type="text" value="ringtone.wav"/>
	Automatic Reset to Default Settings	<input checked="" type="radio"/> disabled <input type="radio"/> enabled
	keep current user-settings replace current user-settings with firmwares default-settings	
	Current Settings	
Own IP-Address	192.168.0.77	
Update-Server IP	192.168.0.76	
Testfile Name	alive.txt	
Image Name	ulimage.ext2	
Busytone	busytone.wav	
Dialtone	dialtone.wav	
Ringtone	ringtone.wav	
Step 1: Save Settings		
<input type="button" value="Save Settings"/>		
Step 2: Verify Server Connection		
If successful testfile content will be prompted.		
<input type="button" value="Probe Connection"/>		
Step 3a: Start Update Process or Step 3b: Install New Soundfiles		
<input type="button" value="Update Now"/> <input type="button" value="Install Sounds"/>		

Reset Settings

Here, you can permanently save the current settings under the menu item **“Create User Default Settings”** in order to restore them at a later time if necessary.

The telephone can be reset to its default settings using the keypad (press and hold the number key 1 + R key together for 5 seconds when the handset is on its hook). If this behavior is desired it can be activated here (preset at factory to deactivated).

If **“User Default Settings”** have been created, the telephone can either be reset to these settings or to the **“Factory Default Settings”**.

Master Reset: The telephone can be set to its default settings at any time by means of a **“Master Reset”**. To do this, the handset must be taken off and the following telephone number dialed:

Master Reset = **314159265359



The screenshot displays the web interface of FHF Funke + Huster Fernsig GmbH. The header features the company name and the tagline 'Signalling Devices and Communication Equipment' over a background image of electronic components. A left-hand navigation menu lists 'Info', 'Configuration', and 'System Administration' (with sub-items: 'Username & Password', 'Manual Upgrade', and 'Reset Settings'). The main content area is titled 'Create User Default Settings' and includes a 'Create' button. Below this is a section 'Reset to Factory Default via Keypad of Phone' with radio buttons for 'disabled' (selected) and 'enabled'. Further down is a 'Remote Software Reset' section with two 'Reset Now' buttons: 'Reset All Settings to User Default Settings' and 'Reset All Settings to Factory Default Settings'. At the bottom of the main area are 'Apply Changes' and 'Reboot Phone' buttons.

General notes

Service

You have purchased a modern FHF product which has undergone a thorough quality control. If you have any questions regarding the telephone or if there is a disturbance, even after the guarantee period, please contact FHF. Have the type designation and article number ready when doing so (please see the type plate for this data).

Servicing and maintenance

The telephone requires no maintenance. Nonetheless, cleaning should be carried out from time to time in areas of application with a high level of contamination due to dust, grease, oil etc. The handset and the device are to be wiped down using a damp cleaning cloth.

Caution! Never use pointed objects for cleaning. Please avoid using any other cleaning and scouring agents.

Lubricants/greases such as oils, fats etc. must NOT (!) be applied to moving housing parts!

Warnings and safety instructions

This device is a weatherproof telephone especially for operation in rough industrial environments. The following warnings and safety instructions are to be considered:

1. A correct connection is to be ensured. The flexible cord is to be laid in such a way that there is no stumbling hazard.
2. The degree of protection IP 66 is only ensured when the housing is closed.
3. The telephone may only be operated under the ambient conditions specified (see "Technical Data"). Adverse ambient conditions, such as too high or too low an ambient temperature, are not permissible since these encourage the failure of electronic components.
4. It is to be ensured that the telephone, the connection line etc. are not damaged. If these are damaged then operating the telephone is not permissible.
5. Legal and commercial regulations, accident prevention regulations and electrical codes are to be considered when operating the telephone.
6. Only original spare parts are permissible when carrying out repairs. These must be exchanged in a technically correct manner. Using other replacement parts may cause damages and would lead to the warranty expiring.
7. Before repairing or exchanging the telephone it must be disconnected from the power supply. If maintaining or repairing the live device is unavoidable, this may only be carried out by specialist personnel.
8. The seals necessary for the tightness of the housing must not be damaged during assembly and disassembly.
9. The prescribed position of normal use is to be considered.
10. Changes to the product which serve for technical advancement may be made without being announced beforehand.
11. In accordance with EN60950-1:2006, the relay must not be subjected to voltages of greater than 42.4 V peak value or 60 V DC voltage.

Technical data

Connection data	
Power supply	Power over Ethernet in accordance with IEEE 802.3af
Separate DC voltage supply	24 V _{DC} ... 48 V _{DC}
Power requirement	1.3 W
Connection	
LAN	Housing plug-in connector RJ45 ports (10/100 Mbit/s)
Relay and sep. DC voltage supply (mechanical)	Screwed cable gland M16 x 1.5 for cable diameter 5 ÷ 9 mm Screw terminals internal
Relay (electrical)	V _{AC max} 30 V V _{DC max} 60 V I _{max} 2A ≤ 30 V _{DC} 1A > 30 V _{DC} 1A ≤ 30 V _{AC}
Protocol	SIP (RFC3261)
Codecs	G.711 A-Law, G.711 μ-Law
Tone call volume	When housing cover open approx. 90 dB(A) at a distance of 1 m When housing cover closed approx. 65 dB(A) at a distance of 1 m
Housing (height x width x depth)	336 x 250 x 110 mm
Weight	2.6 kg
Normal operating position	Vertical wall assembly
Handset	
Mouthpiece	Electret microphone
Earphone capsule	Dynamic capsule with magnetic field generation
Environmental conditions	
Ambient operating temperature	-40°C... +55°C
Transport and storage temperature	-55°C... +70°C
Degree of protection in accordance with IEC60529	IP 66 (closed)

Declaration of conformity

FHF Funke + Huster Fernsig GmbH declares that the telephone InduTel complies with the fundamental requirements and other relevant stipulations of the directive 1999/5/EC (R&TTE).

If problems should arise during operation nonetheless, then please contact the technical support of FHF.

Directives

The device complies with the following directives:

R&TTE directive 1999/5/EC

Low-voltage directive 2006/95/EC

EMC directive 2004/108/EC

RoHS directive 2011/65/EC

Conformity with the directives specified above
is confirmed by the CE mark.



Disposal



Electrical and electronic old devices marked with this symbol may contain hazardous substances for humans and the environment. For this reason, they must not be disposed of together with unsorted municipal waste (domestic refuse). In order to protect our environment, there are therefore public collection points available for the disposal of the electrical and electronic old devices marked with this symbol.

Subject to alterations
or errors



FHF Funke+Huster Fernsig GmbH

Gewerbeallee 15-19 · D-45478 Mülheim an der Ruhr
Phone +49/208/82 68-0 · Fax +49/208/82 68-286
<http://www.fhf.de> · e-mail: info@fhf.de

www.malux.se