

RESERVDELAR/TILLBEHÖR


Art. nr	Typ	Vikt kg	Material
583025	Kupa eLLK 92-18W		Makrolom
583027	Kupa eLLK 92-36W		
583029	Kupa eLLK 92-58W		
583170	Drossel eLLK 92-2x18W		
583174	Drossel eLLK 92-2x36W		
583176	Drossel eLLK 92-2x58W		
583177	Drossel eLLK 92-1x58W		
583182	Drossel eLLK 92 Nöd 2x18W Ni		
583184	Drossel eLLK 92 Nöd 2x36W Ni		
141250	M8 trekantnyckel träskaft		Stål
141365	J 7 trekantnyckelsats metall M4-M16		
583129	Batteri eLLK92 eBK 93, grå		
583128	Batteri eLLK92 NI, svart 2710-2		
583131	Batteri eLLK92 NIB, svart 2710-3		
580457	Adaptersats eLLM 2xM25 5-pol		
583084	Reservdelssats med microbrytare		
583082	Komplett insats 2x36W		
583510	Verktyg för demontering eLLK 92		



Kupa



Drossel


 Trekantnyckel
Art. nr: 141365

 Adaptersats
Art. nr: 580457

 Verktyg för demontering
Art. nr: 583510